

CFU

Compact Filter Unit

Bigger isn't always better. The Compact Filter Unit provides you with the best filtration at a size you can take anywhere. Tried and true, the CFU is the ultimate filtration system in power and mobility. And with easy to change cartridge style MF90s, you can rest easy knowing your filtration will always exceed your expectations.



hyprofiltration.com/



Small size, huge results.

Designed specifically for limited space operations, the CFU maximizes power in a minimal package. Use the ergonomic handle to hoist the CFU to provide filtration directly within turbine nacelles or filter straight from the barrel to take out contaminants before they can ever reach your equipment.



The first stage of success.

Staged filtration allows a range of media selections for particulate and water removal to deliver ISO Codes right on target. Choose from six element configurations to get the perfect CFU for your toughest contamination problems.



Media matters.

DPE rated filter elements stay true to efficiency ratings and ensure the highest level of particulate capture and retention capabilities. And with media options down to $\beta_{3\mu} \geq 4000$ you can be sure contamination stays exactly where you want it: out of your fluid.



Redefines standard filtration.

Knowledge of your system is the ultimate tool in the fight against contamination. With upstream and downstream sample ports located on every machine, the standard CFUs are anything but standard.



Different by design.

Built from lightweight aluminum and engineered for portability, the CFU is perfectly designed to filter new fluids during transfer and top-off bulk oil before use. For fluids already in service, use the CFU to flush them through the high efficiency elements for unparalleled levels of fluid cleanliness.



Completely customizable.

Every CFU can be specifically tailored to the job at hand so you get the perfect solution to suit your needs. With a variety of flow rates and power options, even the ability to color coordinate each CFU to your existing safety standards, the possibilities are endless for what you can do with the CFU.



CFU Quick Guide

CFUM9 model shown (2x MF90 in series)

Closed ergonomic handle for easy lifting/hoisting

Filter assembly ΔP gauge

Inlet sample port

Outlet sample port

CFU outlet

MF90 Filter Assembly

9" bowl with HP90NL9 series filter element

Electric motor

Lightweight aluminum frame

Non-slip rubber feet



Filter Sizing Guidelines

Filter Sizing Guidelines and Viscosity Conversion

Effective filter sizing requires consideration of flow rate, viscosity (operating and cold start), fluid type and degree of filtration. When properly sized, bypass during cold start can be avoided/minimized and optimum element efficiency and life achieved. The filter assembly differential pressure values provided for sizing differ for each media code, and assume 32 cSt (150 SUS) viscosity and 0.86 fluid specific gravity. Use the following steps to calculate clean element assembly pressure drop.

Calculate ΔP coefficient for actual viscosity

Using Saybolt Universal Seconds (SUS)

$$\Delta P \text{ Coefficient} = \frac{\text{Actual Operating Viscosity}^1 \text{ (SUS)}}{150} \times \frac{\text{Actual Specific Gravity}}{0.86}$$

Using Centistokes (cSt)

$$\Delta P \text{ Coefficient} = \frac{\text{Actual Operating Viscosity}^1 \text{ (cSt)}}{32} \times \frac{\text{Actual Specific Gravity}}{0.86}$$

Calculate actual clean filter assembly ΔP at both operating and cold start viscosity

$$\text{Actual Assembly Clean } \Delta P = \text{Flow Rate} \times \frac{\Delta P \text{ Coefficient (from calculation above)}}{\text{Assembly } \Delta P \text{ Factor (from sizing table)}}$$

Sizing recommendations to optimize performance and permit future flexibility

- To avoid or minimize bypass during cold start the actual assembly clean ΔP calculation should be repeated for start-up conditions if cold starts are frequent.
- Actual assembly clean ΔP should not exceed 10% of bypass ΔP gauge/indicator set point at normal operating viscosity.
- If suitable assembly size is approaching the upper limit of the recommended flow rate at the desired degree of filtration consider increasing the assembly to the next larger size if a finer degree of filtration might be preferred in the future. This practice allows the future flexibility to enhance fluid cleanliness without compromising clean ΔP or filter element life.
- Once a suitable filter assembly size is determined consider increasing the assembly to the next larger size to optimize filter element life and avoid bypass during cold start.
- When using water glycol or other specified synthetics we recommend increasing the filter assembly by 1~2 sizes.

CFU Filter Sizing Guidelines

ΔP Factors ¹	Model	Length	Units	Media						
				1M	3M	6M	10M	16M	25M	**W
MF90	L9		psid/gpm	0.270	0.228	0.177	0.159	0.155	0.149	0.027
			bard/lpm	0.005	0.004	0.003	0.003	0.003	0.003	0.000
MF110	L8		psid/gpm	0.250	0.211	0.164	0.147	0.144	0.138	0.025
			bard/lpm	0.005	0.004	0.003	0.003	0.003	0.003	0.000
	L11		psid/gpm	0.176	0.149	0.115	0.103	0.101	0.097	0.018
			bard/lpm	0.003	0.003	0.002	0.002	0.002	0.002	0.000

Max flow rates and ΔP factors assume $\mu = 150$ SUS, 32 cSt. See filter assembly sizing guideline for viscosity conversion formula on page 22 for viscosity change.



CFU Specifications

Dimensions ¹	Height 21" (54 cm)	Length 21" (54 cm)	Width 12" (31 cm)	Weight 47 lbs (21 kg)	
Connections	Inlet ¾" male JIC with 37° flare	Outlet ½" male JIC with 37° flare	Hoses ¾" x 8 ft (2.4 m) suction female JIC or BSPP swivel ½" x 8 ft (2.4 m) discharge female JIC or BSPP swivel		
Operating Temperature	Fluid Temperature 30°F to 225°F (0°C to 105°C)		Ambient Temperature -4°F to 104°F (-20C to 40C)		
ΔP Indicator Trigger	22 psi (1.5 bar). Consult factory for other options.				
Filter Assembly Bypass	25 psid (1.7 bard). Consult factory for other options.				
Materials of Construction	Frame Powder coated aluminum	Filter Assembly Aluminum head	Hoses Reinforced synthetic	Wands Stainless steel	Element Bypass Valve Nylon
Electric Motor	TEFC, 56C frame 7/16 hp, 1450-1750 RPM				
Electric Connection	15' (4.6 m) cord included installed on machine. ²				
Pump	Positive displacement gear pump with relief valve. Maximum pressure on pump inlet 15 psi (1 bar). Consult factory for higher pressures.				
Pneumatic Option Air Consumption	~15 cfm @ 60 psi ³				
Media Description	M G8 Dualglass, our latest generation of DFE rated, high performance glass media for all hydraulic & lubrication fluids. $\beta_{x_{CJ}} \geq 4000$ ($\beta_x \geq 200$)	A G8 Dualglass high performance media combined with water removal scrim. $\beta_{x_{CJ}} \geq 4000$ ($\beta_x \geq 200$)	W Stainless steel wire mesh media $\beta_{x_{CJ}} \geq 2$ ($\beta_x \geq 2$)		
Replacement Elements	To determine replacement elements, use corresponding codes from your equipment part number:				
	Model	Filter Element Part Number	Example		
	CFUD	HP75L8 - [Media Selection Code] [Seal Code]	HP75L8-12MB		
	CFUM9	HP90L9 - [Media Selection Code] [Seal Code]	HP90NL9-16MB		
	CFUM2	HP110L11 - [Media Selection Code] [Seal Code]	HP110NL11-6AV		
Viscosity	Max viscosity rated for 200 cSt. ⁴				
Fluid Compatibility	Petroleum and mineral based fluids (standard). For specified synthetics contact factory for compatibility with fluorocarbon seal option. For phosphate ester (P9) or skydrol fluid (S9) compatibility select fluid compatibility from special options.				
Hazardous Environment Options	Select pneumatic powered unit (Power Option 00) or explosion proof NEC Article 501, Class 1, Division 1, Group C+D. Call for IEC, Atex or other requirements. If Explosion Proof option (X-) selected, no electrical cord will be included.				

¹Dimensions are approximations taken from base model and will vary according to options chosen.

²Selecting pneumatic power option removes electric cord.

³Air consumption values are estimated maximums and will vary with regulator setting.


⁴When sized and installed appropriately. Contact factory for applications above 200 cSt for sizing requirements.



hyprofiltration.com/



CFU Part Number Builder



Model	Filter Assemblies	Filter Elements
D	1 x S75D Spin-On filter assembly	2 x HP75L8-*** filter elements in parallel flow
M2	1 x MF110 cartridge housing	1 x HP110NL11-*** filter element
M9	2 x MF90 cartridge housings	2 x HP90NL9-*** filter elements in series flow

Flow Rate²	05	0.5 gpm (1.7 lpm)
	1	1 gpm (3.7 lpm)
	2	2 gpm (7.5 lpm)
	5	5 gpm (18.9 lpm)

Power Options Contact factory for options not listed	Electrical - Dual Rated	Explosion Proof	Pneumatic			
	21	208-230V, 1 P, 50Hz, 1450 RPM	X11	110 V ac, 1P, 50Hz, 1450 RPM	00	Pneumatically driven air motor & PD pump. FRI & flow meter included.
	22	208-230V, 1 P, 60Hz, 1750 RPM	X12	120 V ac, 1P, 60Hz, 1750 RPM		
	65	110 - 120 V ac, 1P, 50 / 60Hz, 1450 / 1750 RPM	X21	220 V ac, 1P, 50Hz, 1450 RPM		
		X22	208-230 V ac, 1P, 60Hz, 1750 RPM			
Explosion proof - Class 1, Division 1, Group C+D per NEC 501 – Ready for outdoor use						

Hose Connection	G	Female BSPP swivel hose ends, no wands
	S	Female JIC swivel hose ends, no wands
	W	Female JIC swivel hose ends, with wands

Special Options	B	Complete filter bypass line	P9³	Phosphate ester fluid compatibility modification
	C	CE marked for machinery safety directive 2006/42/EC	S9⁴	Skydrol fluid compatibility modification
	J	Add pressure gauge between pump & filter assembly	U	CUL/CSU
	M	Total system flow meter (120 cSt max)	Z	On site start-up training

Media Selection	G8 Dualglass		G8 Dualglass + water removal		Stainless wire mesh	
	1M	$\beta_{3[C]} \geq 4000$	3A	$\beta_{4[C]} \geq 4000$	25W	25 μ nominal
	3M	$\beta_{4[C]} \geq 4000$	6A	$\beta_{6[C]} \geq 4000$	40W	40 μ nominal
	6M	$\beta_{6[C]} \geq 4000$	10A	$\beta_{11[C]} \geq 4000$	74W	74 μ nominal
	10M	$\beta_{11[C]} \geq 4000$	25A	$\beta_{22[C]} \geq 4000$	149W	149 μ nominal
	16M	$\beta_{16[C]} \geq 4000$				
25M	$\beta_{22[C]} \geq 4000$					

Seals	B	Nitrile (Buna)
	V	Fluorocarbon
	E-WS⁵	EPR seals + stainless steel support mesh

¹When selected, omit Media 2 option from part number builder.

²Nominal flow rates at 60 Hz motor speeds.

³When selected, must be paired with Seal option "V." Contact factory for more information or assistance in fluid compatibility.

⁴When selected, must be paired with Seal option "E-WS." Contact factory for more information or assistance in fluid compatibility.

⁵Only available in 3M media for HP75L8 series elements.

For all up to date option details and compatibilities, please reference our [Contamination Solutions Price List](#) or contact customer service.



Filtration starts with the filter.

Lower ISO Codes: Lower Total Cost of Ownership Hy-Pro filter elements deliver lower operating ISO Codes so you know your fluids are always clean, meaning lower total cost of ownership and reducing element consumption, downtime, repairs, and efficiency losses.

DFE Rated Filter Elements DFE is Hy-Pro's proprietary testing process which extends ISO 16889 Multi Pass testing to include real world, dynamic conditions and ensures that our filter elements excel in your most demanding hydraulic and lube applications.

Upgrade Your Filtration Keeping fluids clean results in big reliability gains and upgrading to Hy-Pro filter elements is the first step to clean oil and improved efficiency.

Advanced Media Options DFE glass media maintaining efficiency to $\beta_{3[\mu]} > 4000$, Dualglass + water removal media to remove free and emulsified water, stainless wire mesh for coarse filtration applications, and Dynafuzz stainless fiber media for EHC and aerospace applications.

Delivery in days, not weeks From a massive inventory of ready-to-ship filter elements to flexible manufacturing processes, Hy-Pro is equipped for incredibly fast response time to ensure you get your filter elements and protect your uptime.

More than just filtration Purchasing Hy-Pro filter elements means you not only get the best filters, you also get the unrivaled support, training, knowledge and expertise of the Hy-Pro team working shoulder-to-shoulder with you to eliminate fluid contamination.



Want to find out more? Get in touch.

hyprofiltration.com
info@hyprofiltration.com
+1 317 849 3535

© 2023 Hy-Pro Corporation. All rights reserved.



MKTLITFCE-CFU-052623-EM